



Description: [Tail light](#)
Part Number: 311048-311092
Application: 2007-2008 Toyota Tundra



Tools needed: T27 Torque bit socket.

Step 1: Use the t27 torque bit socket to remove the two screws holding in the tail light.



Step 2: Under the vehicle bed unplug the wire harness.

Step 3: Unclip the wire harness from the frame.

Step 4: Take the tail light off from the vehicle.



Step 5: Put in the new Anzo led tail light into the vehicle.

Step 6: Plug in the new Anzo wire harness into the original socket of the vehicle.

Step 7: Test all functions making sure they work properly before driving.

