

## Installation Instructions:

Part Number: 531077, 531076,  
531021 & 531050

Ford F-250/350/450 (99-14)



Completely read all the instructions before installation  
Improper installation will void warranty

### Step 1



**Tools needed:**  
Phillips Screw Driver

### Step 2



Remove the two phillips screws from the OEM third brake light housing.

### Step 3



Carefully pull out the OEM third brake light housing from the vehicle.

### Step 4



Remove the OEM third brake light by disconnecting the power source.

### Step 5



Remove the Anzo third brake light out of its box.

### Step 6



Install Anzo third brake light by reversing steps 2 to 4.

### Step 7

