



Completely read all the instructions before installation  
Improper installation will void warranty

**Step 1**

**Tools needed:**  
Phillips Screw Driver

**Step 2**

Remove the two phillips screws from the OEM [third brake light](#) housing.

**Step 3**

Carefully pull out the OEM third brake light housing from the vehicle.

**Step 4**

Remove the OEM third brake light by disconnecting the power source.

**Step 5**

Remove the Anzo third brake light out of its box.

**Step 6**

Install Anzo third brake light by reversing steps 2 to 4.

**Step 7**