



Tools Needed: Phillips screwdriver



Step 1: Locate the two phillips screw and remove them with a phillips screwdriver.



Step 2: Pull off the 3rd brake light from the vehicle.



Step 3: Locate the wire harness and unplug it from the light.



Step 4: Take out the new Anzo light and peel off the backing from the blue resistor and place inside the housing.



Step 5: Plug in the new Anzo 3rd brake light.



Step 6: Screw in the light using the two phillips screw removed from step 1.



Step 7: Test all functions making sure everything works before driving.