



Completely read all the instructions before installation
Improper installation will void warranty

Step 1

Tools needed:
Phillips Screw Driver

Step 2

Remove the two phillips screws from the OEM third brake light housing.

Step 3

Carefully pull out the OEM third brake light housing from the vehicle.

Step 4

Remove the OEM third brake light by disconnecting the power source.

Step 5

Remove the Anzo third brake light out of its box.

Step 6

Install Anzo third [brake light](#) by reversing steps 2 to 4.

Step 7