



**Read complete instructions before installation!  
Improper installation may void warranty**



**Tools Needed**  
8mm socket and wrench



Remove the two 8mm bolts on the inside of the tailgate jam.



Carefully remove the stock taillight by pulling out ward.



Remove the light sockets by twisting them



Pull your new light out of the box and inspect it for any damage.



Remove the stickers from the holes.



Install your light sockets in the new light by twisting them in.



Install the new light onto the vehicle. Bolt the bolts back in.



Check for proper functions before operating your vehicle on the highway.