



Description: [Taillight](#)
Part Number: 211114, 211115
Application: Nissan Frontier 98-04



Tools needed
10mm socket and ratchet

If you have a bed liner pull it back
and remove the 2 bolts holding
the light in.

Gently remove the light from the
vehicle by pulling outward



Remove the 3 sockets from the
back of the stock light housing

Insert the light sockets in the new
Anzo light housing. The reverse
light will be moved to the center
hole and the turn signal moves
to the bottom hole.

Bolt the new tail light back in place
and test all functions before
operating vehicle.