



Description: [Taillight](#)  
Part Number: 211114, 211115  
Application: Nissan Frontier 98-04

---



Tools needed  
10mm socket and ratchet

If you have a bed liner pull it back  
and remove the 2 bolts holding  
the light in.

Gently remove the light from the  
vehicle by pulling outward



Remove the 3 sockets from the  
back of the stock light housing

Insert the light sockets in the new  
Anzo light housing. The reverse  
light will be moved to the center  
hole and the turn signal moves  
to the bottom hole.

Bolt the new tail light back in place  
and test all functions before  
operating vehicle.