



Tools needed
Phillips screwdriver



Remove the 4 screw from the lens



Pull the taillight straight out and unclip the plug harness.



Plug the new connector into the stock harness.



Bolt the tail light back onto the vehicle. Check all functions of the light before operating on the highway.