



**Read complete instructions
before installation!
Improper installation may
void warranty**



Tools needed
Flat head screw driver
7/16 socket and ratchet



Remove the two plugs located
on the trunk cover by pulling
outward.



Using your flat head pull the 4
push pins out that hold the
trunk cover in.



Flip the trunk cover forward
so you can access the 3 7/16 nuts
that hold the tail light in.



Remove the 3 7/16 nuts



After removing the nuts pull the
taillight straight out.



Remove the light sockets from
the light.



If you have the upgraded harness
for the 2010 style you will need to
remove the old harness. Push the
body plug out.



Unclip the harness, re route the
new harness through the hole and
plug it in. Again this part is only for
the 2010 style



Twist the sockets back into place



Re-install the new taillight by
reversing the instructions.



Check all functionality of the new
lights before operating on any
highway.