



**Read complete instructions before installation!**  
**Improper installation may void warranty**

Description: [Tail light](#)

Part Number: 311057-311058-311004-311005-311006-311059-311079  
Application: 1988-1998 Chevy Full-size - GMC Pick-up/ 1992-1994 GMC Jimmy - Chevy Blazer FS / 1992-1999 Chevy Suburban - Tahoe- GMC Yukon-Yukon XL / 1999-2000 Cadillac Escalade



Tools Needed: Phillips Screwdriver

Step 1: Open the tail gate and locate the two phillips screw and remove them.



Step 2: Pull the tail light off from the vehicle.



Step 3: Unplug the tail light wire harness.



Step 4: Take out the new Anzo tail light from the box.



Step 5: Plug in the tail light wire harness into the new Anzo tail light.



Step 6: Test all functions to make sure of proper installation before driving.