



Tools needed
8mm Socket and Ratchet



Remove the two 8mm bolts
holding the taillights in.



Pull the taillight outward .



Remove the light sockets by
twisting and pulling outward.



Be sure to clean the pockets so
the resistor will adhere to the
vehicle.



Remove the stock 3157 light
bulbs from the sockets by
pulling straight out.



Peel the backing off of the resistors
and place them in the open
pockets out of the way. Pressing
firmly against the vehicle.



Plug the 3157 pigtail coming from
the taillight into the light socket.
Be sure to match the black wires
from the taillight and the socket
on the same side.



Install the taillight back onto the
vehicle.



Be sure to check all functions
before operating on the highway.