

rilla Installation Instruction

Day 100/01

AUTO PAR	TS SPECIALIST I	wc	Grille I	nstallatio	n Insi	ruction		Rev. 180401
Part#	GR0	1GEI29T&H	Applica	tion For 2	For 2010-2015 Cadillac SRX			
	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Mesh Grille	1	Stainless stee	3	Lock Nut	4	6-32
	2	Stud	4	6-32× 2"	4	L-Brackets	4	/
Install Notes: Overlay $\boxed{\hspace{0.1cm}}$ Replacement $\boxed{\hspace{0.1cm}}$ Drill $\boxed{\hspace{0.1cm}}$ Cut $\boxed{\hspace{0.1cm}}$								
Installation								
1. Identify th parts list.	e grille	& hardware with		a 3/4 drill bit, di the screws or ove.				s towards the end
			0		31— S			



4. Remove 2 clips from each side fender well.



5. Remove 12 bolts on the inner bumper shell between the outer bolts.



6. Place mesh grille through the factory bumper opening.



7. From behind place an L-Bracket on the threaded studs on the mesh grille and tighten with provided 6-32 Lock Nuts.

8. Installation completed!!!

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!