

Item

Part Name

Grille Installation Instruction

Rev. 150116

Description

Part# GR01GFG62T Application 06~10 Cadillac DTS – Low Bumper Stainless Steel Mesh Grille

Description Item

Part Name

		item Par		rt Na	me	QIY Descrip		scripti	tion Item		11	Part Name				QIY	Description
Parts L	ist	1	Mesh (Grille		1 Stainless		iless ste	eel	3		K-Lock	Nuts			8	6-32
		2	Studs			8 6-32×1		×1 1/2	2"	4		L Bracl	kets			8	1/2" ×1/2"
Install Notes: Overlay Replacement ×							×	D	rill	×		Cut	×				
Step	Step Description								illustration								
1	Identify the grille & hardware with parts list.																
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.																
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille.Be sure the bolts are through the OEM grille shell.								N/A								
4	Secure billet grille using the lock nuts from the back side of the OEM grille shell.From the backside of the bumper; place an L bracket and k-lock nut on each. Make sure that the L brackets wrap onto the factory bumper plastic													\			
5	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.							en I	N/A								
6	Reinstall the black plastic cover which was removed in step 2.							noved	N/A								
7	Installation completed!!!							1	N/A								

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!