

Grille Installation Instruction

Rev. 120901

| Part# | GR | GR02GEE21H | | Application | | 06~07 AUDI A4 - Stainless Steel Mesh Grille | | | | | |
|---------------------------------------|---|--------------------|--------------|-------------|-------------|---|--------------|------------------|------------|------------------------------|--|
| | Iten | ı Pa | art Name | QTY | Des | scription | Item | Part Name | QTY | Description | |
| Dorde I | 1 | Me | sh Grille | 1 | Stainless | steel | 4 | Flat Tab | 10 | 6-32 | |
| Parts Lis | 2 | Stu | ıd | 10 | 6-32×2" | | 5 | Washer | 10 | 1 | |
| | 3 | Loc | k Nut | 10 | 6-32 | | 6 | 1 | 1 | 1 | |
| Install Notes: Overlay Replacement | | | | | | | | | | | |
| Step | Description | | | | | | illustration | | | | |
| 1 | Identify the grille & hardware with parts list. | | | | | | | | | | |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | | | | | | | | | | |
| | Secure trear of th | ud to the the. | nreaded h | noles on t | the | 10-6-32×2"Studs | | | | | |
| 4 | Center the grille. Be | ne grill sure t | e into the o | opening o | f the facto | ory grille shell.\ shell. | ou need | l mark and drill | three hole | es on the top of the factory | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 120901

| Part# | | GR02GEE21H | Application | 06~07 AUDI A4 - Stainless Steel Mesh Grille | | | | | |
|-------|--|---|---|---|--|--|--|--|--|
| 5 | Sec was she | cure grille using flat tab shers from the back sic ell. | s and lock nuts and de of the OEM grille | Flat Tabs Lock Nut ,Flat Tab and Washer | | | | | |
| 6 | Make sure the grille is centered and tighten the fasteners. | | | | | | | | |
| 7 | Reinstall the black plastic cover which was removed in step 1. | | | | | | | | |
| 8 | Inst | tallation completed!!! | | | | | | | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!