



PATENT PRODUCT

Grille Installation Instruction

Part#	GR03FEG49 C/S/J	<i>Application</i>	For 2006-2013 Chevy Impala LS Without Fog Light/2006-2013 Chevy Impala LT Without Fog Light
--------------	--------------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Stainless steel	4	Screws	8	6-32x1.5"
	2	Hex Flange Nuts	14	6-32	5	Screws	6	6-32x2"
	3	Brackets 1	6		6	Brackets 2	4	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
	Identify the grille & hardware with parts list.	

FOR CENTER BILLET GRILLE:

1	Place one screw through each of the tabs on the billet grille.
2	Center the billet grille into the factory opening.
3	Place the powder coated brackets over the screws.
4	Secure the billet grille to the vehicle using the hex flange nuts.

FOR SIDE BILLET GRILLES:

1	Place one screw through each of the tabs on the billet grille.
2	Place each of the bumper inserts into the bumper pockets.
3	Center each of the inserts, and then from the backside of the grilles, place the powder coated brackets.
4	Secure the brackets, and the inserts to the vehicle using the hex flange nuts..

Installation completed!!!

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!