

## **PATENT PRODUCT** Grille Installation Instruction

Rev. 190801

Part#	GR03FFD51 C/S/J		Application		For 2007-2014 Chevy Avalanche /Suburban / Tahoe Not For Hybrid								
		Item Part		Name QTY		Description		ltem	Part Name		QTY	Description	
Parts L	ist	st 1 Billet Grille		e 2		Stainless steel		3	Bolts		8	6-32 × 2 ″	
		2 Toggle Nuts			8 6-32								
Install N	Note	es: Ov	Overlay √ Replaceme			nent $\times$	D	orill 🗆	Cut	×			
Step	Description						illustration						
1	Identify the grille & hardware with parts list.												
2	Optional: remove the plastic cover on the bottom of the OEM front bumper, which will allow access to the rear of the OEM grille.												
3	Insert the screws into the weld tab hole from front side of the billet grille.						Picture for reference only. This is not actual grille. Weld tab Screw Toggle nut						
4	Center the billet grille onto the OEM grille. Press & insert the toggle nuts on to the rear of the OEM grille through the gap between the horizontal bars.												
5	Secure the grille using the toggle nuts and screws from the front side of the billet grille with a screw driver.												
6	Installation completed!!!												

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!