




Grille Installation Instruction

Rev. 190501

Part#	GR03GEG06 T/H	Application	For 1994-1999 Chevy Blazer Not For S-10 (6 Bars)/ 1994-1999 Chevy C/K Pickup Not For C2500 Single Light (6 Bars)/ 1994-1999 Chevy Suburban/ Tahoe (6 Bars)
-------	------------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	2	Stainless Steel	3	Studs	16	0.138-32×1.5 "
	2	Flat Tabs	8		4	Hex Flange Nuts	16	0.138-32

Install Notes: Overlay	<input checked="" type="checkbox"/>	Replacement	<input type="checkbox"/>	Drill	<input type="checkbox"/>	Cut	<input type="checkbox"/>
------------------------	-------------------------------------	-------------	--------------------------	-------	--------------------------	-----	--------------------------

Step	Description	illustration
1	Identify the grille & hardware with parts list. Note: The top grille is just about 1/4" shorter than the bottom grille.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Secure the stud to the threaded holes on the rear of the grille. Hold the grille up to the opening of the factory shell. Be sure the studs are through the OEM grille shell.	
4	Secure the grille using the flat tabs and hex flange nuts from the back side of the OEM grille shell.	
5	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.	
6	Repeat steps 3 – 5 for the bottom grille installation.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!