



Grille Installation Instruction

Part#	GR03GEI43T	Application	For 2012-2014 Chevy Malibu Main Upper
-------	------------	-------------	---------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	2	Stainless steel	3	Lock Nuts	12	6-32
	2	Flat Tab	12		4	Studs	12	6-32 × 1"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Secure the stud to threaded holes on the rear of the grille.	
4	Center the grille into the opening of the factory grille shell. Be sure the stud are through the OEM grille shell. You need mark and drill six holes.	
5	Secure grille using the lock nuts from the back side of the OEM grille shell.	<p>At the red mark, please mark and drill holes.</p>
6	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!