

Part#	GR03GEI97 T/H	Application	For 2014-2015 Chevy Camaro LT/LS With RS Package					
Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless steel	4	Lock Nuts	2	6-32
	2	Small T-Brackets	24	/	5	Black Fender Washers	2	/
	3	Grille Fasteners	24	/				
Install Notes: Overlay ☒ Replacement ☐ Drill ☐ Cut ☐								
Installation								
 1. Identify the grille & hardware with parts list.			 2. From underneath the front of the vehicle use a 10mm socket and ratchet to remove six bolts where the bottom of the bumper cover attaches to the bottom plastic splash guards (Fig 1).			 3. Inside of each front wheel fender well remove three Torx screws with a T15 Torx bit (Fig 2).		
 4. These are the screws that secure the fender well splash guard to the front bumper cover. Pull back the plastic splash guard in the fender well and remove four 10mm bolts from each fenderwell (Fig 3).			 5. Now open the hood and locate four bolts in the metal cover plate that surrounds the hood latch and remove them. Remove six plastic pop clips from along the top of the bumper cover under the hood with a flat screwdriver (Fig 4).			6. Remove the metal plate that surrounds the hood latch. With a helper pull the entire bumper cover forward only about a foot and reach behind the passenger side of the bumper cover and unplug the fog lights from the wiring harness. Now you can fully remove the bumper cover. With the bumper cover sitting on a workbench use a flat screwdriver to unlatch the plastic reinforcement and plastic latches that hold the plastic grille air intake vent to the bumper cover and remove the air intake vent and the plastic factory grille insert.		

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Part#	GR03GEI97 T/H	Application	For 2014-2015 Chevy Camaro LT/LS With RS Package
 7. From the back of the factory bumper cover take the mesh grille and install it onto the latches that the plastic factory grille insert was re-moved from, the mesh grille has slots in it that will line up with the factory latches. Press the mesh grille on flush. Install the T-brackets into the small slots in the mesh grille where the larger slots are (Fig 5).			
 8. Now install the grille fastener clips onto the plastic latches to secure the mesh grille to the bumper cover (Fig 6).			
 9. Reinstall the black plastic reinforcement onto the back of the bumper cover (Fig 7).			
 10. Use two black washers and lock nuts to secure the plastic reinforcement to the threaded studs on the back of the mesh grille.			
11. Reinstall the bumper cover in the reverse order from above, remember to reconnect the fog lamps.			
12. Installation completed!!!			

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!