

Grille Installation Instruction

Part#	GR03GFC16T/H		Application For 20 Mode		015-2019 Chevy Colorado Not For ZR2					
	Item	Part Name	QTY	Desc	ription	Item	Part Name	QTY	Description	
Parts Lis	t 1	Mesh Grille	2 Stainless steel		ss steel	3	Fully Threaded Studs	11	0.138-32UNC L= 3 "	
	2	Flat Tab	11			4	Flange Lock Nuts	11	0.138-32UNC	
Install Notes: Overlay Replacement Drill Cut Cut										
Step	Description					illustration				
1	Identify the grille & hardware with parts list.									
/	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.									
3	Install the fully threaded studs into the backside of the mesh grille.									
4	Hold the grille against the OEM grille shell, center and mark holes for drilling. Remove grille and drill holes according to your mark. Be sure the studs are through the OEM grille shell.								les	
	Secure grille using the flat tabs and lock nuts from the back side of the OEM grille shell.									
6	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.									
7	Reinstall the black plastic cover which was removed in step 2.									
8	Installation completed!!!									

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!