

Part#	G	R030	GFC42T/H	Applica	tion	For 201:	2015 CHEVY CRUZE							
		ltem	Part Nan	ne QT	Y	Description		Item	Part Nan	ne	QTY	Description		
Dente L		1	Mesh Grille	2	S	tainless stee		4	Lock Nuts		12	6-32		
Parts L	IST	2	Tabs	12				5	Studs		8	6-32×1″		
		3	Studs		6	·32×1.5″								
Install Notes: Overlay \checkmark Replacement \times Drill \checkmark Cur									√ Cut	×				
Step	Description							illustration						
	Identify the grille & hardware with parts list.													
1														
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.													
3	Center the grille into the opening of the factory grille shell. Secure the stud to the threaded holes on the front of the grille. Be sure the stud are through the OEM grille shell. Remove the billet and drill six holes at each mark.													
4	Secure grille using the lock nuts from the back side of the OEM grille shell.													
5	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.													
6	Reinstall the black plastic cover which was removed in step 2.													
7	Installation completed!!!													

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Page 1 of 1