






# Grille Installation Instruction

Part#	GR03GFC43H	Application	<b>For 2015-2016 CHEVY CRUZE Lower Bumper</b>
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	2	Stainless steel	4	Lock Nuts	7	6-32
	2	Tabs	7		5	Studs	4	6-32 × 1.5"
	3	Studs	3	6-32 × 1"				

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Center the grille into the opening of the factory grille shell. Secure the stud to the threaded holes on the front of the grille. Be sure the stud are through the OEM grille shell.	
4	Secure grille using the lock nuts from the back side of the OEM grille shell.	<div data-bbox="778 1070 1508 1310"> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 5px;">Here you need drill a hole at each mark.</div>  </div>
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!