

**PN: C76671T**

**2009 Tahoe – Stainless Steel Mesh Grille**

Hardware

8 -- 6-32×2" Studs	8 -- 6-32×1 1/2" Studs	16 -- 6-32 Kept Nuts
4 -- 2-Hole Tabs	8 -- J Hooks	16 -- Washers

- (1) Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.
- (2) Thread a stud in each nut welded to the grille. From the rear, place a tab on each stud. Now thread a nut and a washer on each stud.
- (3) Make sure the insert is centered and tighten the hardware.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!