




Grille Installation Instruction

Part#	GR03GGI19S	Application	2007-2014 Chevy Avalanche Not For Z71 Model Tow Hook Must be Removed/2007-2014 Chevy Suburban Not For Z71 Model Tow Hook Must be Removed/2007-2014 Chevy Tahoe Not For Z71 or Hybrid Model Tow Hook Must be Removed
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	4	Stainless steel	4	Tab(two holes)	2	130mm
2	Tab(one hole)	4	70mm	5	Nylon Lock Nuts	16	6-32	
3	Screws	8	6-32 × 2"		Long Stainless J-Brackets	4		
	Short Stainless J-Brackets	4	8#					

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Start with main grille section. Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut and a washer on each screw.	
4	Center the grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
5	Secure grille using the nuts and washes from the back side of the OEM grille shell.	
6	Continue to the bumper grille section. Remove the plastic filler panel from each of the two bumper opening.	
7	Center the wire mesh grilles into each of the bumper openings.	
8	Place the short stainless J-brackets over the fully threaded studs at the top of the wire mesh grille and hook the other end over the lip on the backside of the bumper opening and hold in place using the nylon nuts.	
9	Place the long stainless J-brackets over the fully threaded studs at the bottom of the wire mesh grille and hook the other side over the lip on the backside of the bumper opening and hold in place using the nylon nuts.	
10	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.	
11	Reinstall the black plastic cover which was removed in step 2.	
12	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!