



PATENT PRODUCT


Grille Installation Instruction

Rev. 190601

Part#	GR03HEB41S	<i>Application</i>	For 1988-1992 Chevy Camaro
--------------	------------	--------------------	-----------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Screws	4	6-32×2"
	2	Nuts	4	Nuts	4	Flange Brackets	4	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Insert a screw in each tab welded to the grille. Center the billet grille into the opening of the factory grille shell. Be sure the screws are through the OEM grille shell.	
4	From the rear, place a flange brackets on each screw. Now thread a nut on each screw.	
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!