

5

the front of the grille.Be sure the bolts are through

Secure billet grille using the nuts from the back side

the OEM grille shell.

PATENT PRODUCT Grille Installation Instruction

Part#	GR03HEJ08S	Application	For 1973-1980 Chevy Blazer / 1973-1980 Chevy C/K Pickup / 1973-1980 Chevy Suburban / 1973-1980 GMC C/K Pickup /
			1973-1980 GMC Suburban

Part#	GR03HEJ08S		Application 1973-1980 Chevy Suburban / 1973-1980 GMC C/K Pickup / 1973-1980 GMC Suburban							
Item Part Name QTY		QTY	Description	Item	Part Name	QTY	Description			
Dawie I.	1	Billet Gri	Billet Grille		Stainless steel	4	Hex Bolts	8	1/4" -20×3/4"	
Parts Li	St 2	Support	Support Bracket-L			5	Kep Nuts	8	1/4" ×20	
	3	Support	Support Bracket-R							
Install N	otes: C	verlay	× Replac	ement	√ Drill	√	Cut ×			
Step		D	escription			illustration				
1	Identify tl	ne grille & ha	rdware with part	s list.						
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.									
3	is necess of the r	ary to removadiator supp	ctory vertical gri ve two 5/16" bo port and one o ee 5/16" bolts	olts in the n top of	front the N/A					
4	grille she	II. Secure the	into the opening bolt to the threads Be sure the bolt	aded hole	es on N/A					

of the OEM grille shell. Make sure the billet grille is centered and tighten 6 N/A the fasteners. Reinstall the black plastic cover which was removed N/A 7 in step 2. 8 N/A Installation completed!!! 9 On 1973-1974 trucks it requires marking and drilling four 5/16 " diameter holes in radiator support for attachment.

N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!