




# PATENT PRODUCT

## Grille Installation Instruction

<b>Part#</b>	GR04FFD39 C/S/J	<b>Application</b>	<b>For 2005-2010 Dodge Charger Not For SRT8</b>
--------------	--------------------	--------------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	2	Screws	8	8# × 1"

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Center the bumper insert into the opening .Mark the mounting tabs to the plastic bars in the bumper. Drill a 1/16" hole at each tab.	
4	Use the screws to hold the billet in place. Do not over-tighten the screws.	
5	Reinstall the black plastic cover which was removed in step 2.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!