

Grille Installation Instruction

Part#	GF	GR04GEJ37T/H		Application Fo		or 2005-2007 Dodge Magnum Except SRT8				
	Item	Part Name	QTY	QTY Description		Item	Part Name	QTY	Description	
Parts Li	1	Mesh Grille	4	4 Stainless s		4	'J' Hooks	16		
Faits Li	2	Nylon Lock Nu	t 16	6-32		5	Screws	16	6-32×1″	
	3	Flat Washers	16	6#						
Install Notes: Overlay $\boxed{\hspace{1em}}$ Replacement $\boxed{\hspace{1em}}\times$ Drill $\boxed{\hspace{1em}}\times$ Cut $\boxed{\hspace{1em}}\times$										
Step	Description					illustration				
1	Identify the grille & hardware with parts list.									
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.									
3	Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.									
4	Thread a screw in each nut welded to the grille. From the back slide a J hook and washer onto each machine screw. Thread the Nylon Lock nuts onto the screws by hand. Center the grille into the opening. Make sure the J hooks wrap around the grille mesh. Use a screwdriver and wretch to tighten the hardware. Do not over-tighten the hardware.									
5	Make sure the billet grille is centered and tighten the fasteners.									
6	Reinstall the black plastic cover which was removed in step 2.									
7	Installation completed!!!									

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!