	A	2	5		Grille	e Ins	stall	atior	n Inst	ruc	ction				
Part#	G	GR04GGI82T			Application		For 2005-2007 Dodge Magnum Except SRT8								
	Iter	n	Part Nam	e	QTY	De	escrip	otion	Item	P	art Name	QT	Y	Description	Ī
	1	Mesh Grille			6 Stain		less steel		5	'J' Hooks		16			
Parts Li	ist 2	Ν	ylon Lock	Nut	24	6-32			6	Screws		16		6-32×1″	
	3	F	lat Washers		16 6#					Screws		8		6-32×1 1/2″	
	4	2-	2-Hole Tab		4				8	Washers		8			
Install N	lotes: (s: Overlay $$			Replacement		×	Dr	ill 🗌	×	Cut	×			
Step	Description							illustration							
1	Identify the grille & hardware with parts list.														
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.														
3	Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.														
4	Start from top piece. Thread a screw in each nut welded to the grille. From the back slide a J hook and washer onto each machine screw. Thread the Nylon Lock nuts onto the screws by hand. Center the grille into the opening. Make sure the J hooks wrap around the grille mesh. Use a screwdriver and wretch to tighten the hardware. Do not over-tighten the hardware.														
5			ottom piece. asher on eac			w in ea	ach nu	ut welded	d to the g	grille.	From the re	ar, plac	e a t	ab on screw. Now thread	
6	Make su 2.	re the	e billet grille is	s cente	ered and	d tighte	en the	fastener	s. Reins	tall th	ne black plas	tic cove	er wh	ich was removed in step	_
7	Installati	on co	mpleted.												

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Installation completed.