

PATENT PRODUCT

Grille Installation Instruction

Rev. 190801

Part#	rt# F65356C/S/J		Lariat/Ha Application Lariat/Ha Lariat/Ha		5-2007 Ford Excursion /2005-2007 Ford F-250 Not For farley Davidson/2005-2007 Ford F-350 Not For farley Davidson/2005-2007 Ford F-450 Not For farley Davidson/2005-2007 Ford F-550 Not For farley Davidson			
	Item	Part Nam	e QTY	Description	ltem	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	5	'L' BracketBottoms	2	
Parts L	.ist 2	U-Clip Nut	s 4	8#	6	Truss Socket Tapping Screws	4	8×1″
	3	Hex Bolts	2	1/4″ -20×3/4″	7	Flat Washers	4	1/4 ″
	4	Nuts	2	1/4″-20				
Install I	Notes: O	verlay √	Rep	placement ×	Dri	ill 🛛 Cut 🗡		
Step	Description				illustration			
1	Identify the grille & hardware with parts list.							
					_			
2	Pop hood of the grill		lack plast	tic cover (on top of C	DEM grill	e / front panel) from vehicle. This wi	ill allow ac	ccess to the rear
2 3	of the grill Slide the welded to	e shell. U-clip nuts or the rear of th	to the 'L e billet. Th	' brackets provide here are two tabs in	ed. Cente the cent	e / front panel) from vehicle. This wi er the U-clip nuts over the smaller s ter and two along the bottom. As sh the screws completely at this time.	ets of hol	es. Note the tabs
	of the grill Slide the welded to the bracket brackets i 'L' sha bumper. U secure the The brack	e shell. U-clip nuts or the rear of th ets to the bille billet into the nto the openir oed brackets i Jse the 1/4 " t e short end of	to the 'L e billet. Th using the bumper o g first. Th nount to fa olts, nuts the brack of the alu	" brackets provide here are two tabs in a 1 " screws. Do not opening; insert the e short end of the actory holes in the and washers to ets to the bumper. minum and can be	ed. Cente the cent	er the U-clip nuts over the smaller s ter and two along the bottom. As sh	ets of hol	es. Note the tabs
3	of the grill Slide the welded to the bracket brackets i 'L' sha bumper. I secure the The brack bent for p	e shell. U-clip nuts or the rear of th ets to the bille billet into the nto the openir bed brackets of Jse the 1/4" th e short end of rets are made roper alignme	to the 'L e billet. The using the bumper of g first. The nount to fa- olts, nuts the bracked of the alu	" brackets provide here are two tabs in a 1 " screws. Do not opening; insert the e short end of the actory holes in the and washers to ets to the bumper. minum and can be illet insert.	ed. Cente the cent tighten t	er the U-clip nuts over the smaller s ter and two along the bottom. As sh the screws completely at this time.	ets of hol	es. Note the tabs
3	of the grill Slide the welded to the bracket brackets i 'L' sha bumper. I secure the The brack bent for p	e shell. U-clip nuts or the rear of th ets to the bille e billet into the nto the openir bed brackets in Jse the 1/4" th e short end of rets are made roper alignme	to the 'L e billet. The using the bumper of g first. The nount to fa- olts, nuts the bracked of the alu hat of the b	" brackets provide here are two tabs in a 1 " screws. Do not opening; insert the e short end of the actory holes in the and washers to ets to the bumper. minum and can be illet insert.	ed. Cente the cent tighten t	er the U-clip nuts over the smaller s ter and two along the bottom. As sh the screws completely at this time.	ets of hol	es. Note the tabs

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!