



# PATENT PRODUCT

## Grille Installation Instruction

<b>Part#</b>	GR06FFJ17C/S/J	<b>Application</b>	<b>For 2005-2009 Ford Mustang V6</b>
--------------	----------------	--------------------	--------------------------------------

<b>Parts List</b>	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	4	Studs	4	10-24 × 1.5 "
	2	J Hooks	2		5	Lock Nuts	4	10-24
	3	Flange Brackets	2		6	Washers	4	

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Thread a 1.5" stud into the inner tabs on the insert. From the back of the insert, slide a J hook, washer and lock nut on screws (thread the nuts by hand).	
4	Now center the billet over the bumper openings. Wrap the J hooks around the top of the center opening. Install the flange brackets with the remaining screws, nuts and washers on the outer tabs. The flange brackets hold the billet to the honeycomb area in the bumper cover opening. Use a Phillips screwdriver and wrench to snug the hardware down until the billet is held firmly in place.	
5	Reinstall the black plastic cover which was removed in step 2.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!