

Grille Installation Instruction

Part#	G	GR06GFD01S/K Application			on	For 2018 and up Ford F-150 Lower Bumper (drilling may be required for XL/XLT/King Ranch/Plantinum)							
		Item	Part Nam	ie	QTY	Desc	ription	Item		Part l	Name	QTY	Description
Parts Lis	st	1	Mesh Grille		1	Stainle	ess steel	3		U-Clip		4	8#
		2	2 Screw		4 8		2"	4		Two-hole ta	b	2	
Install Notes: Overlay Replacement													
Step	Description					Illustration							
1	Identify the grille and hardware with parts list.												
2	Re	Remove license plate from the bumper. (Fig 1&2) Fig 1 Fig 2											
3	Attach U-Clips on the two-hole tab, one at each hole, make sure the small hole on the clip is pointing at the opposite direction from the tab bending angle. (Fig 3) Fig 3												
4	ali for	Put two-hole tab on the back of the grille and align with the welded tab. Thread in screws for the top section first to secure two-hole tabs on the welded tabs. (Fig 4) Fig 4 Bottom											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Part#	GR06GFD01S/K	Application	For 2018 and up Ford F-150 Lower Bumper (drilling may be required for XL/XLT/King Ranch/Plantinum)					
5	Hold the billet insert up to the opening of the factory shell, and make sure that it is centered. Rotate the two-hole tab and make sure it clamps the back of the OEM grille shell. Then, thread in two more screws on the bottom section to secure the two-hole tabs on the welded tabs. Tighten the screws, but not over tighten.							
7	Installation completed.							

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!