

PATENT PRODUCT

Grille Installation Instruction

C/S/J HO		Part#	GR06HEJ99 C/S/J	Application	For 250 Hole 550
----------	--	-------	--------------------	-------------	---------------------------

For 1999-2004 Ford Excursion 1 PC Cover 3 Holes/1999-2004 Ford F-250 1 PC Cover 3 Holes/1999-2004 Ford F-350 1 PC Cover 3 Holes/1999-2004 Ford F-450 1 PC Cover 3 Holes/1999-2004 Ford F-550 1 PC Cover 3 Holes

	Item	Pa	art Name	QTY	Description	ltem	Part Name	QTY	Description
Parts Lis	t 1	Billet Gril	le	1	Stainless steel	3	Flat Nuts	5	10#
	2	Truss Hea	ad Tapping Screws	5	10×3/4″				
Install No	tes: Ov	verlay	× Replacen	nent	√ Drill _	\checkmark	Cut		
Step		Inst	truction			Pho	to		Note
1	Place protect chrome grille s and sc	grille she from scr finish. hown in	grille shell from Il on blanket to atching or dam Note accent lin Use a scoring s shown (Figure e peeling.	help aging ie on blade		Figure 7			
	 Using a cutting tool (die grinder, air saw, razor knife, saber saw) carefully cut out the three center sections. See Figure 2. 			saw)		Figur	re 2	a C p	ut only the rgent (gray olored) ortion of rille.
	<u>she</u>		<u>so cut out the</u> le full opening		E.	Figur	e 3		
2	 Smooth out the cut surface with a flat file a grinding tool. See Figure 4 – 7. You must leave the tabs shown in figure 5 & 9 in order to install the billet grille. 			Figur		Tab on	shell igure 5	2 2 2 2 7	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



PATENT PRODUCT Grille Installation Instruction

Part# GR06HEJ99 C/S/J Application Application 250 1 PC Cover 3 Holes/1999-2004 Ford F-350 1 PC Cover 3 Holes/1999-2004 Ford F-450 1 PC Cover 3 Holes/1999-2004 Ford F- 550 1 PC Cover 3 Holes
--

Step	Instruction	Photo	Note
3	Place the billet grille into the grille shell, center the grille for proper fitment. You may need to bend a slight radius into the billet grille. To do this, face the billet grille away from you. Next place your hands around the billet grille with your thumbs in the U-Channel push the forward.	N/A	
4	Once the grille is adjusted for the best fitment, place the grille back into the grille shell. Mark and drill the four lower mounting points of the grille, securing the two outside brackets first. See Figure 7 and 8.	Figure 9	
5	Next, push down on the billet grille until it sits flush into the grille shell, then mark and drill your two upper mounting points. You will need to use a very short screw driver to fit between the grille and the grille shell	N/A	Installation is now complete!
	<u>3 Openings</u>	Full Opening	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!