

PATENT PRODUCT Grille Installation Instruction


Rev. 180701

Part#	GR()6HEH28C&1 Application				For 2011-2016 Ford F-250 / F-350 / F-450 / F-550 SD							
	lte	m	Part Nar	ne	QTY	Desc	ription	Item	Р	Part Name	QTY	Description
Parts Lis	st 1		Billet Grille		1 Stainle		ss steel	3	Flat tabs		7	#8
	2 Screws			7 #8×3/4		+ ″						
Install N	otes: Overlay × Replacement						Drill \checkmark Cut \checkmark					
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Remove the factory grille from the vehicle. There are 4 bolts along the top of the grille under the hood that need to be removed The top of the grille will be loose, pull the bottom out until the latches pop loose and remove the grille.											
3	With the grille removed from the vehicle remove the 5 plastic pop clips and one 10/32" bolt from the top plate of the factory grille, remover the top plate (Fig 1).											
4	Now remove 7 plastic pop rivets from along the top edge of the factory grille assembly. Use a pointy object or a small punch to press in the center of the top (Fig 2).											
5	The pop rivet will break and will not be re-used. Remove the pop rivet with a pair of pillars (Fig3).											
	$\left[\begin{array}{c} \hline \\ Fig 1 \end{array} \right] \left[\begin{array}{c} \hline \\ Fig 2 \end{array} \right] \left[\begin{array}{c} \hline \\ Fig 3 \end{array} \right] \left[\begin{array}{c} Fig 3 \end{array} \right] \left[\begin{array}{c$											
6	Now you will remove the 2 chrome trim bars from the front of the factory grille. From the backside of the grille, unlatch the 7 plastic latches holding the chrome trim bars secure with a flat screwdriver (fig 4).											
7	Pull the chrome trim bars off the grille. Now you will separate the front and back section of the factory grille. On the backside of the factory grille there are 6 plastic latches along the top, 6 along the bottom and 2 on each side, unlatch these with a flat screwdriver and separate the front and back sections of the factory grille (Fig 5).											
8	Remove the Ford logo, there are 4 plastic latches and 1 nut holding it to the grille (Fig 6).											

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



PATENT PRODUCT Grille Installation Instruction



The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



PATENT PRODUCT Grille Installation Instruction

Rev. 180701 For Application Part# GR06HFH28C&J 2011-2016 Ford F-250 / F-350 / F-450 / F-550 SD Fig 11 Fig 12 Fig 13 Now take the hardware provided with the billet grille and insert the screws through the hole in the tabs on 12 the billet grille and through the factory grille where you drilled the holes, use the nut plates to secure the screws (Fig 14). Fig 14 Remove the masking tape and reinstall the factory grille with the billet installed back onto the vehicle. If you 13 would like to reinstall the ford logo, use 3m adhesive tape on the backside to secure it to the billet grille. 14 Installation completed.

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

View other car and truck custom grilles made by APG on our website.