



PATENT PRODUCT


Grille Installation Instruction

Rev. 190301

Part#	GR07FEG04 C/S/J	Application	<i>For 1999-2000 GMC Sierra 1500 Not For HD/2000-2006 GMC Yukon /2001-2006 GMC Yukon Denali /2001-2002 GMC Sierra All Model/2001-2001 GMC Sierra C3 /2002-2006 GMC Sierra Denali</i>
--------------	----------------------------	--------------------	--

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	1	Stainless steel	3	Truss Head Tapping Screws	4	8# × 3 "
	2	Flat Tabs	4		4	U- Clip Nuts	4	8#

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove filler panel that goes from the grille shell and covers over the radiator. This allows access to the backside of the grille shell without removing it.	
3	Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.	
4	Place one screw through each of the welded tabs on the billet grille.	
5	Place a U-clip nut over each of the holes on the single hole flat tab.	
6	Where the screws come through the grille shell, place a tab in align with the screw and tighten. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. DO NOT OVER TIGHTEN SCREWS.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

[View other car and truck custom grilles made by APG on our website.](#)