




Grille Installation Instruction

Part#	GR07FEG14J	Application	For 1994-1998 GMC C/K Pickup with Stacked Lights For 1994-1999 GMC Suburban Composite Plastic Lights For 1994-1998 GMC Yukon
--------------	------------	--------------------	--

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	1	Stainless steel	3	U- Clip Nuts	4	8#
	2	Mounting Clips	4		4	Truss Head Tapping Screws	4	8×2"

Install Notes:
 Overlay
 Replacement
 Drill
 Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. Put a screw through the hole in each tab on the billet grille.	N/A
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell. Slide a U-clip nut onto each mounting clip	N/A
4	Position the billet grille into the grille shell opening, around the GMC logo. Secure billet grille using the nuts from the back side of the OEM grille shell.	N/A
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!