

Grille Installation Instruction

Rev. 140701

Part#	GF	R07GF	D75T	Арр	lication	n 200	7-2012 G	MC Sie	rra 1500 M	ain Upp	per
		Item	Part N	ame	QTY	Desc	cription	Item	Part Name	QTY	Description
Parts L		1	Mesh Grille		1	Stainless steel		4	Tab 1	5	1
	.IST	2	Stud		10	10-24×2"		5	Tab 2	5	1
		3	Lock Nut		10	10-24		6	Washer	10	10#
Install N	lote	s: Ove	erlay \	/	Replac	ement	× Dr	ill ×	Cut	<	
Step			Des	script	ion				illust	ration	
1	Identify the grille & hardware with parts list.										
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.										
3		Secure the stud to the threaded holes on the rear of the grille.									
4	Cei	nter the	grille into	the ope	ening of t	he factory	grille shell. B	e sure the	studs are throug	gh the OE	M grille shell.
5	Secure grille using the tabs and lock nuts and washers from the back side of the OEM grille shell.							Was	Tab 2	Lock Nut	
	NA-	ko over	the avilla :	0.00-4-	arod and	tighton 45 -	factories	NAME OF THE OWNER, OF THE OWNER, OF THE OWNER, OF THE OWNER, OWNER, OWNER, OWNER, OWNER, OWNER, OWNER, OWNER,		Tab 1	
6		Make sure the grille is centered and tighten the fasteners.									
7		Reinstall the black plastic cover which was removed in step 2.									
8	Installation completed!!!										

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 140701

Part#	GR07GFD75T	Application	2007-2012 GMC Sierra 1500	Main Upper
-------	------------	-------------	---------------------------	------------

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation

We are not responsible for any damage caused by the installation. Thank you for choosing our product!