

Grille Installation Instruction

Part#	GR07LEG71H Application 2003-2006 GMC Sierra1500 (Not For C3 Model) Logo Covered Main Upper Covered Main Upper									
		ltem	Part Nam	e QTY	Descri	ption	ltem	Part Name	QTY	Description
Parts Li	ict	1	Mesh Grille	1	Stainless stee	el	4	Lock Nut	6	10-24
Faits L	151	2	Stud	6	10-24× 3″		5	Flat Tab	6	1
		3	washer	6	1		6	1	1	1
Install N	lote	es: Ov	verlay 🗸	Repla	cement	× Dri		Cut	×	
Step	Description					illustration				
1	Identify the grille & hardware with parts list.					N/A				
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.									
3	Secure the stud to the threaded holes on the rear of the grille.									ids
4	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.									
5	Secure grille using the flat tabs and lock nuts and washers from the back side of the OEM grille shell.									
6	Make sure the grille is centered and tighten the fasteners.									
7	Reinstall the black plastic cover which was removed in step 2.									
8	Installation completed!!!									
The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit										

to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!

View other car and truck custom grilles made by APG on our website.