

## Grille Installation Instruction

Part#	GR07LEI73L Application		For 2014-2015 GMC Sierra 1500							
	Item	Part N	Name	QTY	Description	ltem	Part Name	QTY	Description	
Parts List	t 1	Rivet Grill	e	1	Stainless steel	3	Flange brackets(small)	2	/	
	2	L bracket		2	/	4	Flange brackets	3	2 1/2″ x70°	
Install Notes: Overlay $\times$ Replacement $\checkmark$ Drill $\times$ Cut $\checkmark$										
Step		Des	cription			illustration				
	Identify the grille & hardware with parts list.									
	You may need to remove the black plastic cover (at the bottom of OEM front bumper) from vehicle. This will allow access to the rear of the grille shell.									
3	Start of by removing the twelve plastic pop clips along the top of the radiator cover using flat screw driver(Fig 1). Remove the plastic radiator cover(Fig 2). Remove the four 10mm bolts located along the top of the factory grill(Fig 3). From underneath the vehicle remove four 10mm bolts from the bottom backside of the factory grille, two are located in the middle area and two are located underneath each headlamp(Fig 4-7). Pull the sides of the plastic bumper top pad outward and pull the forward and carefully remove the bumper top pad(Fig8 & Fig 9)									
4	factory gr the top c Remove	rill shell.(Fig of the factor the factory g	10). Pull o ry grille wh grill from the	up on th iile pullir e vehicle	ng the bottom of e plastic plate alo ng forward (Fig 1 e . Separate the fr &Fig13&Fig14)	ong 11).			Fig 12	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!



## Grille Installation Instruction

Rev. 190501

Part#	GR07LEI73L	Application	For 2014-2015 GMC Sierra 1500				
5	Take the black plastic back section of the factory grill, you will need to cut out the center section. On the backside of the plastic use a cutting wheel and grinder to cut along the ridge around the opening highlighted white. Smooth the cut edge with the grinding wheel . The cut black section should look like as shown.						
6	Take the three 2 1/2 the parts bag and in top of the grille.						
7	Make sure the grille is centered and tighten the fasteners.						
8	Reinstall the plastic shroud with the fasteners removed in Step 4.						
9	Installation completed!!!						

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

View other car and truck custom grilles made by APG on our website.