

Grille Installation Instruction

GR08GGA18T/H A		Арр	oplication For		2003-2006 Honda Element With Logo Show				
Item Part Name		ne	QTY	Description		Item	Part Name	QTY	Description
ist 1 Mesh Grille		1	Stainless Steel		3	Studs	4	6-32X 1"	
2 Nylon Lock Nuts		4	6-32		4	"U" Tabs	4		
Install Notes: Overlay \checkmark Replacement \times Drill \times Cut \times									
Description					illustration				
Identify the grille & hardware with parts list.									
Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.									
Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut and a washer on each screw.									
Make sure the insert is centered and tighten the hardware.									
Installation completed!!!									
	t 1 2 otes: Ov dentify the Remove t grille is ce Thread a and a was Make sure	t 1 Mesh Grille 2 Nylon Lock M otes: Overlay √ Descr dentify the grille & hard Remove the grille & hard grille is centered. Thread a screw in each and a washer on each s	1 Mesh Grille 2 Nylon Lock Nuts otes: Overlay √ Remove √ Re Remove the grille & hardware Remove the grille from the brille is centered. Thread a screw in each nut and a washer on each screw. Make sure the insert is centered.	t 1 Mesh Grille 1 2 Nylon Lock Nuts 4 otes: Overlay √ Replacen Description dentify the grille & hardware with pa Remove the grille from the box. Tes grille is centered. Thread a screw in each nut welded and a washer on each screw. Make sure the insert is centered and	t 1 Mesh Grille 1 Stainless S 2 Nylon Lock Nuts 4 6-32 otes: Overlay √ Replacement × Description ✓ Mathematical Action of the second of	t 1 Mesh Grille 1 Stainless Steel 2 Nylon Lock Nuts 4 6-32 otes: Overlay √ Replacement × Dri Description dentify the grille & hardware with parts list. Remove the grille from the box. Test fit the grille to magnille is centered.	1 Mesh Grille 1 Stainless Steel 3 2 Nylon Lock Nuts 4 6-32 4 otes: Overlay √ Replacement × Drill × Description × dentify the grille & hardware with parts list. Remove the grille from the box. Test fit the grille to make surgrille is centered. Thread a screw in each nut welded to the grille. From the real and a washer on each screw. Make sure the insert is centered and tighten the hardware.	1 Mesh Grille 1 Stainless Steel 3 Studs 2 Nylon Lock Nuts 4 6-32 4 "U" Tabs otes: Overlay √ Replacement × Drill × Cut Description illus dentify the grille & hardware with parts list. illus Remove the grille from the box. Test fit the grille to make sure that it fits in t grille is centered. Thread a screw in each nut welded to the grille. From the rear, place a tab c and a washer on each screw. Make sure the insert is centered and tighten the hardware. Make sure the insert is centered and tighten the hardware.	t 1 Mesh Grille 1 Stainless Steel 3 Studs 4 2 Nylon Lock Nuts 4 6-32 4 "U" Tabs 4 otes: Overlay √ Replacement × Drill × Cut × otes: Overlay √ Replacement × Drill × Cut × otes: Overlay √ Replacement × Drill × Cut × otes: Overlay √ Replacement × Drill × Cut × otes: Overlay √ Replacement × Drill × Cut × otes: Overlay √ Replacement × Drill × Cut × dentify the grille & hardware with parts list. illustration illustration illustration Remove the grille from the box. Test fit the grille to make sure that it fits in the shell prille is centered. Thread a screw in each nut welded to the grille. From the rear, place a tab on each sund a washer on each screw.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

View other car and truck custom grilles made by APG on our website.