

PN: GR13GFG75T
2010 Mazda CX9 Main Upper

Hardware

14-- 6-32×1 1/2" Screws 14- 6-32 K-Lock Nuts

14-- Flat Tabs

- (1) Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. If it is not proper, you need cut the bars of the shell horizontally. Make sure the grille is centered.
- (2) Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut on each screw. (about 7 studs, nuts and tabs)
- (3) You need to mark and drill several holes on the perimeter of the grille shell and then thread a screw in each nut welded to the grille, from the rear, place a tab on each screw, now thread a nut on each screw. (remaining studs, nuts and tabs)
- (4) Make sure the insert is centered and tighten the hardware.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!