




## Grille Installation Instruction

|       |            |             |                                   |
|-------|------------|-------------|-----------------------------------|
| Part# | GR14FGG79J | Application | 2008-2015 Nissan Armada Logo Show |
|-------|------------|-------------|-----------------------------------|

| Parts List | Item | Part Name     | QTY | Description     | Item | Part Name       | QTY | Description |
|------------|------|---------------|-----|-----------------|------|-----------------|-----|-------------|
|            | 1    | Billet Grille | 4   | Stainless steel | 4    | Screws          | 8   | 8# × 3"     |
|            | 2    | Flat Tabs     | 8   |                 | 5    | U- Clip Nuts    | 12  |             |
|            | 3    | J-Hooks       | 4   | 1 1/2"          | 6    | Phillips Screws | 4   | 1 1/4"      |

Install Notes: Overlay  Replacement  Drill  Cut

| Step | Description  | illustration   |
|------|--|--|
| 1    | Identify the grille & hardware with parts list.  |  |
| 2    | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.  |  |
| 3    | Start with the upper section. Place one screw through each of the welded tabs on the billet grille.  |  |
| 4    | Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.   |  |
| 5    | Place a U-clip nut over each of the holes on the flat tabs.  |  |
| 6    | Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.  |  |
| 7    | Move on to the lower section. Factory grille shell must be removed first. On top of the grille; use a small slotted screwdriver to release (1/4 turn) four plastic fasteners. Slightly pull the grille forward. Now release three clips along the bottom of the grille. Remove the grille.       |  |
| 8    | Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.   |  |
| 9    | Install a #8 U-Nut over flat end of J-Hook bracket. Place the grille insert into the factory bumper opening. Install a screw into mounting holes from the front side of grille. Wrap the J hooks around the plastic bars in the bumper. Tighten the hardware. Repeat this process on other side. |  |
| 10   | Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.  |  |
| 11   | Reinstall the black plastic cover which was removed in step 2.   |  |
| 12   | Installation completed!!!  |  |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
We are not responsible for any damage caused by the installation. Thank you for choosing our product!