



## Grille Installation Instruction

Part#	GR14FGI66S	Application	2005-2007 Nissan Pathfinder With Logo Show/2005-2008 Nissan Frontier With Logo Show
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	4	Stainless steel	5	Truss Head Screws	8	6#-32×2"
	2	Kep Nuts	8	6#-32	6	Power Coated Brackets	8	
	3	'J' Hooks	2		7	Screws	2	6-32×2"
	4	Flat Washers	2		8	Nylon Lock Nuts	2	

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Start with the upper section. Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
4	Secure billet grille using the k-lock nuts from the back side of the OEM grille shell.	
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
6	Continue to the lower section. Remove the six fasteners holding the top of the grille in place. Pull the grille forward to access the mounting clips on each end; use a slotted screwdriver to unclip the two fasteners on each side. Now remove the grille by depressing the six clips holding the grille to the bumper cover.	
7	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
8	Install a machine screw into each mounting hole. From the back slide a J hook bracket and washer onto each machine screw. Thread the Nylon Lock nuts onto the screws by hand. Center the billet into the bumper opening. Make sure the J hooks wrap around the grille mesh. Use a screwdriver and wrench to tighten the hardware. Do not over-tighten the hardware.	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

## Grille Installation Instruction

Part#	<i>GR14FGI66S</i>	<i>Application</i>	<b>2005-2007 Nissan Pathfinder With Logo Show/2005-2008 Nissan Frontier With Logo Show</b>
9	Reinstall the black plastic cover which was removed in step 2.		
10	Installation completed!!!		

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!