

## Grille Installation Instruction

Rev. 190301

| Part# | GR14GEB25T/H | Application | For 2009-2014 Nissan Maxima |
|-------|--------------|-------------|-----------------------------|
|-------|--------------|-------------|-----------------------------|

| Parts List | Item | Part Name   | QTY | Description     | Item | Part Name       | QTY | Description |
|------------|------|-------------|-----|-----------------|------|-----------------|-----|-------------|
|            | 1    | Mesh Grille | 1   | Stainless steel | 4    | Nylon Lock Nuts | 4   | 6-32        |
| rails List | 2    | J Hooks     | 2   | 2.5"            | 5    | Studs           | 4   | 6-32×2.5″   |
|            | 3    | J Hooks     | 2   | 1 "             |      |                 |     |             |
|            |      |             |     |                 |      |                 |     |             |

|  | 0 0 1 100K3 Z 1  |              |  |  |  |  |
|--|--|--------------|--|--|--|--|
| Install Notes: Overlay $\boxed{\hspace{1em}}$ Replacement $\boxed{\hspace{1em}}\times$ Drill $\boxed{\hspace{1em}}\times$ Cut $\boxed{\hspace{1em}}\times$ |  |              |  |  |  |  |
| Step   | Description  | illustration |  |  |  |  |
| 1  | Identify the grille & hardware with parts list.  |              |  |  |  |  |
| 2  | Open the hood and remove the factory plastic radiator cover. Remove the factory air intake plate on the driver side of the vehicle. Now remove the factory grille shell; release the molded clips along the perimeter of the grille.   |              |  |  |  |  |
| 3  | Center the grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.  |              |  |  |  |  |
| 4  | Thread a stud in each nut welded to the grille. Start to thread the shorter J hooks onto the top studs. Start to thread the longer J hooks onto the lower studs. Center the grille in place. Wrap the hooks around plastic bars in the openings. Use a 8mm wrench to tighten the hardware. |              |  |  |  |  |
| 5  | Make sure the grille is centered and tighten the fasteners, but do not over-tighten.   |              |  |  |  |  |
| 6  | Re-install the factory upper grille onto the vehicle.  |              |  |  |  |  |
| 7  | Installation completed!!!  |              |  |  |  |  |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!