

Grille Installation Instruction

Rev. 150116

Part# GR14GED13T Application 04-13 Nissan Titan 04-07 Nissan Armada (Lower Bumper)

	Iten		Part Name	QTY Descript		tion Item		Part Name	QTY	Description	
Parts L	iet	1	Mesh Grille	1	Stainless st	eel	4	Lock Nuts	4	6-32	
raits L	ist	2	J hook	4			5	Washer	4		
		3 Thread stud 4 6-		6-32x2 "							
Install Notes: Overlay × Replacement						Drill × Cut ×					
Step	Description					illustration					
1	Identify the grille & hardware with parts list.										
2	Remove the plastic bumper shroud (at the bottom of the front bumper) from the vehicle. This will allow to access to the rear of the bumper opening.										
3	Secure the thread studs into the welded nuts on the rear of the mesh grille insert.					Stud Welded nut					
4	Centre the mesh grille insert into the bumper opening.										
4	Fasten the grille onto the bumper opening with the J hooks, washers & lock nuts						Edge of the bumper J hook Lock Nut & washer Stud NOTE: This picture is for reference only, it shown how to use J hook.				
5	Re-install the plastic bumper shroud which was removed in step 2										
7	Installation completed!!!									OO Q	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!