




Grille Installation Instruction

Rev. 190801

| | | | |
|-------|--------------|-------------|--|
| Part# | GR14GFE05T/H | Application | For 2005-2008 Nissan Frontier /2005-2007 Nissan Pathfinder |
|-------|--------------|-------------|--|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|-------------|-----|-----------------|------|-------------|-----|--------------|
| | 1 | Mesh Grille | 3 | Stainless steel | 4 | Screws | 11 | 10-24×1 1/2" |
| | 2 | Flat Tabs | 11 | | 5 | K-Lock Nuts | 11 | 10-24 |
| | 3 | Washers | 11 | | | | | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|---|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | |
| 3 | Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered. | |
| 4 | Thread a screw in each nut welded to the grille. | |
| 5 | From the rear, place a tab on each screw. Now thread a nut and a washer on each screw. | |
| 6 | Make sure the grille is centered and tighten the fasteners. | |
| 7 | Reinstall the black plastic cover which was removed in step 2. | |
| 8 | Installation completed!!! | |

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Looking for dependable car and truck custom grilles? Rely on APG for quality and long-lasting products.