



Grille Installation Instruction

Part#	GR14HGG65C	Application	2007-2009 Nissan Altima Sedan
-------	------------	-------------	-------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Stainless steel	6	Screws (#6 Head)	5	#8×1 1/4"
	2	U-Nuts	5	8#	7	Extension Brackets	2	5"
	3	L Brackets	4	1/2×1/2	8	L Bracket	1	1/2×2 1/4×9/16
	4	Machine Screws	4	6-32×1.5"	9	Flat Washers	4	6#
	5	Nylon Lock Nuts	4	6-32	10	J Hooks	2	1.5

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the factory grille shell. Use a small screwdriver to pull the center from six fasteners along the top of the grille and bumper cover. Next, lightly pull the top of the grille assembly forward; use a slotted screwdriver to depress the clips on each end of the grille. Use your fingers to depress the molded clips along the bottom of the grille; remove the grille.	
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
4	Slide a u-nut over the small hole in the L brackets (1). Test fit the grille into the opening. The 5" extension brackets secure to the core support (2); aligned with the 1/2" mounting tabs on top of the billet. Install these using the plastic push fasteners. (3) Attach the billet to the extension brackets; do not fully tighten. Use the screws provided. Attach the shorter L brackets along the bottom; on each end (3). Secure the longer L bracket in the center. Close the hood and check the alignment of the billet insert. If necessary, remove the insert and adjust the brackets.	
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
6	Move on to the lower piece. Center the billet over the opening. Remove the insert. Note the tabs welded to the rear of the insert. From the front, insert a screw into each tab on the billet insert.	
7	Install the L brackets on the top; then thread a nut and washer on each screw. Install the J hooks on the bottom. Now place the billet insert over the opening. Wrap the brackets around the factory cross bars; tighten the hardware. Make sure the insert is centered; loosen the hardware and adjust if needed.	
8	Reinstall the black plastic cover which was removed in step 2.	
9	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!