






Part#	GR18FFE73C/J	Application	For 2000-2005 Chrysler PT Cruiser (Not for GT or Turbo models with intercooler)		
--------------	--------------	--------------------	--	--	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	2	Screws	4	#8×3/4"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	 Remove OEM Grille
3	Center the billet insert over the opening in the air dam. Mark the brackets to the factory grille.	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> Mark & Drill holes onto the OEM grille according to the weld tab holes position of billet grille. And then, secure the billet grille on the OEM grille with the screws. </div> 
4	Drill a 1/8" hole at each mark. Re position the billet insert over the opening. Use the #8 screws to secure the billet insert to the opening.	
5	Make sure the billet grille is centered and tighten the fasteners. But do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!