



Grille Installation Instruction

Part#	GR18FFH73J	Application	For 2011-2014 Chrysler 200 Lower Bumper
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Screws	2	6-32 × 1 1/2 "
	2	Toggle Nuts	2	6#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	N/A
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. Remove grilles from the box and identify the top grille from the bottom grille.	N/A
3	Place screws through the welded aluminum tabs on the grille, and attach a toggle nut on the end of each bolt.	N/A
4	Hold the billet insert up to the opening of the factory shell, make sure that it is centered in the grille shell, and push in the toggle nut past the factory grille honeycomb.	N/A
5	Turn the toggle nut so that it is vertical, and tighten. But not over-tighten!	N/A
6	Repeat steps three and four for the remaining seven welded tab on the billet grille.	N/A
7	Reinstall the black plastic cover which was removed in step 2.	N/A
8	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!